



PARTNER[®] ACS and the 2007 Daylight Saving Time Change

Which PARTNER ACS systems will be updated?

Software updates are available for the following PARTNER ACS systems:

- ✓ PARTNER ACS R7
- ✓ PARTNER ACS R6 Basic
- ✓ PARTNER Small Office Edition

What about older releases of PARTNER ACS?

There are no plans to provide software upgrades for any PARTNER ACS older than Release 6.0.

How do I deactivate the Automatic Daylight Savings Time feature?

1. Log in to the PARTNER ACS system in the System Administration mode
 - a. From extension 10 or 11, press **[FEATURE] [0] [0]**
 - b. Press the LEFT intercom button twice
2. Dial **[#] [1] [2] [6]**
3. The default setting is 1 (active). To deactivate, dial 2
4. Exit from System Administration **[FEATURE] [0] [0]**

How do I manually set the time?

1. Log in to the PARTNER ACS system in the System Administration mode
 - a. From extension 10 or 11, press **[FEATURE] [0] [0]**
 - b. Press the LEFT intercom button twice
2. Dial **[#] [1] [0] [3]**
3. Enter the new time in 24-hour notation. For example, to set the time to 2:15pm, press **[1] [4] [1] [5]**
4. Exit from System Administration **[FEATURE] [0] [0]**



PARTNER[®] ACS and the 2007 Daylight Saving Time Change

How do I determine which PARTNER ACS system and release I have?

There are two ways to determine the type and release of your Partner system:

- 1) Using [Feature] [5] [9] (PARTNER ACS systems only)
- 2) Using [Feature] [#] [1] (PARTNER ACS and all older PARTNER systems)

On all PARTNER ACS, PARTNER Small Office Edition and PARTNER Endeavor systems, you can simply dial [FEATURE] [5] [9] from any display telephone. The display will show they type of system, release and software version as indicated in the table below.

Considerations:

- ✓ On some Partner ACS and Endeavor systems, using “Feature 59” is preferable because the beeps provided by “**Feature #1**” are the same for different releases.
- ✓ To “decipher” which PARTNER and Release, see table on next page.

When you use the “**Feature #1**” option, you will hear various beeps from the handset, which correspond with the beeps indicated on the chart below. You must be on an active call on an outside line. You can accomplish this several ways:

- a) Call one of the incoming lines to the PARTNER system, and have the person who answers press [FEATURE] [#] [1]
- b) Pick up an unused line and press [FEATURE] [#] [1]. You will hear the dial tone in the background and possibly an error message.
- c) On PARTNER Plus /PARTNER II/ PARTNER ACS and PARTNER Endeavor systems, you can program a “phantom” line (that doesn't have an actual line installed on it), then select that line and press [FEATURE] [#] [1].

